



1. Install the door bracket .

2. Close the door. The door needs to be relaxed and the cabinet to be unplugged



3. Align the template (P/N 13612) with the .25" diameter wire and with the door bracket cover as shown in picture. The template needs to easy touch the door bracket. Do not push against the door bracket.



4. Once the template is aligned push the template against the cabinet and lift the levers of the two suction cups .

5. Check if the template is firmly attached to the cabinet.



6. Drill the three 19/64" (.297") diameter holes corresponding to the three drilling bushings attached to the template. Drill only through the exterior thin wall of the cabinet. Do not protrude deep into the insulation layer.

